

PARTS LIST

for

KitchenAid®

7 QT. STAND MIXER

RESIDENTIAL – BOWL LIFT

MODELS:

KSM7581WH0 (White)
KSM7581CA0 (Candy Apple)
KSM7581BZ0 (Black Storm)
KSM7581MS0 (Medallion Silver)



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




KITCHENAID

ST. JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

For Model: KSM7581__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COLOR VARIATION PARTS

For Model: KSM7581__0


Illus.	Part	
No.	No.	DESCRIPTION

Colors Subject To Change.
Any Color Not Listed is
No Longer Available.
If Additional Colors Are Added,
This Page Will Be Updated.

1		Motor Housing
	9703311	White
	W10403016	Candy Apple
	W10403017	Black Storm
	W10354887	Medallion Silver
2		Trim Band
	W10234515	Dark Platinum
3		Lower Gearcase
	W10234488	White
	W10403004	Candy Apple
	W10403005	Black Storm
	W10354881	Medallion Silver
4		Planetary
	W10234498	White
	W10403008	Candy Apple
	W10403009	Black Storm
	W10354883	Medallion Silver
5		Bowl Support and Pins
	9703674	White
	W10402998	Candy Apple
	W10402999	Black Storm
	W10354878	Medallion Silver
6		Column and Pins
	9703673	White
	W10402992	Candy Apple
	W10402993	Black Storm
	W10354872	Medallion Silver
7		Base & Foot Assembly
	9703690	White
	W10402986	Candy Apple
	W10402987	Black Storm
	W10354860	Medallion Silver

CASE, GEARING AND PLANETARY UNIT

For Model: KSM7581_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CASE, GEARING AND PLANETARY UNIT


For Model: KSM7581__0

Illus. No.	Part No.	DESCRIPTION
1	**	Gearcase Motor Housing
2	W10395280	Cap, Attachment Hub, Hinged
3	**	Band, Trim
4	W10351843	Screw
5	W10305968	Holder, Control
6	**	Lower Gearcase
7	W10234493	Gear, Ring & Plate to Planetary
8	3400617	Screw
9	3400814	Screw
10	W10234504	Motor, 120 V Assy w/Transmission
11	3400200	Screw
12	W10234530	Control Assembly
13	W10234531	Pin, Groove
14		Cord, Power
	W10234520	White
	W10338492	Black
15	**	Planetary Assembly
16	9703438	Clip, Retaining
17	9706090	Washer
18	W10234643	Gear, Pinion
19	9707223	Pin, Retaining
20	8533910	Washer
21	9708191	Shaft, Agitator
22	9703680	Clip, Retaining
23		Thumb Screw
	W10360791	Black
24	9704677	Pin, Groove

**Refer To Page 3
Color Variation Parts

BASE AND PEDESTAL UNIT

For Model: KSM7581__0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

For Model: KSM7581__0

Illus.	Part	
No.	No.	DESCRIPTION
1		Literature Parts
	W10308004	Use & Care Guide
	W10394312	Repair Parts List
2	9709924	Shield, Pouring
3	W10354778	Bowl, 7 Qt.
4	240185	Pin, Bowl Locating
5	9703474	Latch, Bowl Spring
6	3400018	Screw
7	**	Bowl Support
8	**	Base and Foot Assembly
9	9708649	Foot, Rubber
10	9703307	Clip
11	9706787	Rod, Bowl Lift
12	9237	Spring
13	9703439	Washer
14	8533907	Nut
15	**	Column Assembly
16	W10394561	Beater, Flat
17	W10398839	Hook, Dough
18	9706885	Arm, Bowl Lift
19	W10352664	Whip, Wire
20	9703426	Cam, Adjusting
21	3400863	Screw
22	9706788	Handle, Bowl Lift
23	9703698	Cap, Handle
24	3400200	Screw

**Refer To Page 3
Color Variation Parts

ACCESSORY PARTS

For Model: KSM7581__0

Illus. No.	Part No.	DESCRIPTION
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
	4164749	Food Grinder (FG-A)
W10318099		Grain Mill (KGM0)
	4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
	4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
	4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
	241675	Food Tray (FT)
	4164748	Juicer (JE)
	4164803	Sausage Stuffer Kit (SSA)
	4176597	Grease, Planetary
	8212519	Ice Cream Maker (KICA0WH0)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST